Warning alarm and control without distance limitation

GSM HOME SECURITY SYSTEM

Model: GSM-120 *ISO-9001, CE, IEC1010*

www.YaLAB.com.tw 02-23890101



FEATURES DS-121 x 2 PCs

- * Home security system via GSM mobile phone, no distance limitation.
- * If the house is happened the unusual interrupt, user's mobile phone will receive the alarm SMS message immediately.
- * Two wireless detect switches are included, user can install the DS-121 on the door or window. easily. When the thief interrupt the house, buzzer will sound and send the SMS alarm message to the mobile.
- * Build in alarm buzzer output and control output terminal.





The Art of Measurement

GSM HOME SECURITY SYSTEM

Model: GSM-120

FEATURES

- * Home security system via GSM mobile phone, no distance limitation.
- * If the house is happened the unusual interrupt, user's mobile phone will receive the alarm SMS message immediately.
- * Two wireless detect switches (DS-121, included), user can install the DS-121 on the door or window easily. When the thief interrupt the house, buzzer will sound and send the SMS alarm message to the mobile.
- * Build in alarm buzzer output, wire buzzer is the standard accessory. Wireless alarm buzzer (WB-122) is available as the optional accessory.
- * Build in one relay output, user can control (ON/OFF) the home electrical equipment via the mobile phone.
- * Wireless relay (WR-123) is the optional accessory. When user intend to control the electrical appliance, it is not necessary use the wires to connect the main system if via WR-123.
- * All setting value will be saved into EEPROM IC, no loss.

- * Allow to preset three telephone no., alarm SMS will be send to three users in sequence.
- * After the SMS command send by mobile phone, the confirm message will be send back to the mobile, safety and no loss.
- * SMS delay time, SMS repeat time, buzzer delay time, buzzer repeat time can be preset flexibly.
- * Dot matrix LCD display with back light, can display all the system information clearly.
- * Mobile telephone can call the status of the system.
- * Mobile telephone can ON/OFF the alarm function.
- * Build GSM mobile modem (dual band, 900/1800 MHz).
- * Easy operation and installation, can D.I.Y by the user.
- * Few and limit SMS command. Intelligent application, innovation, wide range, no limitation.
- * Application: Home security system. Building supervision. Industrial security system. Remote control the electrical system (Lighting, Pump, Heater, Refrigerator, Pets feeder..)

| | SPECIFICA | | | | |
|-------------------------|--|--------------------------|---|----------------------------|--|
| DISPLAY | Dot-matrix LCD with back light 16 characters x 2 line. | Operating Temperature | 0 to 50 $^{\circ}\mathrm{C}$ (32 to 122 $^{\circ}\mathrm{F}$) | | |
| GSM Modem | 900/1800 MHz, dual band. | Operating | Less than 80% RH. | | |
| LED | 7 LED Indicators : | Humidity | 2033 (11011 00 70 101). | | |
| Indicators | GSM indicator | Power supply | Main unit | DC 9V, via adapter in. | |
| mucators | System indicator | l ower suppry | Detect Switch | Battery, 006P, DC 9V. | |
| | SMS alarm indicator | Power | Main unit | GSM module working : | |
| | Buzzer alarm off indicator | | * Buzzer silent | Approx. DC 210 mA | |
| | | consumption | buzzei silerit | | |
| | Detect switch indicator | | | GSM module standby : | |
| | Buzzer indicator | | D 1 1 C 11 1 | Approx. DC 125 mA | |
| D 1 1 C 11 I | Control relay indicator | - | Detect Switch | Normal : | |
| Detect Switch Inputs | * Whole system included two " Wireless | | | No current | |
| | detect switches " (DS-121) as the | | | consumption. | |
| | standard accessories. User can install | | | Interrupt : | |
| | DS-121 on the door or window easily. | | | DC 5.8 mA | |
| | When the thief interrupt the house, | Size | Main unit | 193 x 149 x 46 mm | |
| | the buzzer will sound and send the | | | (7.6 x 4.9 x 1.8 inch). | |
| | SMS warning message to the mobile | | Detect Switch | 11 x 3.4 x 2.6 mm | |
| | phone. | | | (4.3 x 1.3 x 1.0 inch). | |
| | * If need more doors (windows) to | Weight | Main unit | 500 g (1.1 LB). | |
| | install the extra " Wireless detect | | Detect Switch | 87 g (0.19 LB). | |
| | switches ", the DS-121 is offered as | | | * Included battery | |
| | the optional accessory. | Accessories | Operation manual | | |
| | * No number of the DS-121 that can be | includes | | | |
| | installed are no limited. Any DS-121 | | | 2 sets | |
| | is interrupted, the system will send | | AC 100V-240V/DC (9V, 1A) power adapter 1 PC Antenna 1 PC | | |
| | the warning alarm message to mobile. | | | | |
| Buzzer Output | Buzzer output terminal can connect the | - | | | |
| | " Wire buzzer " (standard accessory). | | | Buzzer with two wires 1 PC | |
| | When thief interrupt the house, the | | | sponge 1 set | |
| | buzzer will sound. | Optional | Wireless Buzzer unit, Model : WB-122 | | |
| Relay Output | * Build one control relay output (NO, | Accessories | Wireless Relay unit, Model: WR-123 | | |
| Total Carpar | normal open) , user can control the | Size | Main unit | 193 x 149 x 46 mm | |
| | home electrical appliance via mobile | 0.20 | man am | (7.6 x 4.9 x 1.8 inch). | |
| | phone. | | Detect Switch | 11 x 3.4 x 2.6 mm | |
| | * Max. load of control relay : | | Detect Switch | (4.3 x 1.3 x 1.0 inch). | |
| | 1 ACA/250 ACV | Weight | Main unit | 500 g (1.1 LB). | |
| | 1 DCA/24 DCV | Weight | Detect Switch | 87 g (0.19 LB). | |
| Wireless | Can cooperate the " Wireless Buzzer " | _ | Detect Switch | * Included battery | |
| Buzzer | (WB-122, optional). User can hide | Accessories | Operation manus | | |
| Interface | the main system of GSM-120 and only | includes | Operation manual 1 PC Wireless detect switch, DS-121 | | |
| ппенасе | present the WB-122 in the obviously | liticidaes | AC 100V-240V/DC (9V, 1A) | | |
| | | | | | |
| | place, then the thief will not find the | | | | |
| Mirologo | main system (GSM-120) easily. | - | | 1 PC | |
| Wireless | Can cooperate the "Wireless Relay unit " | | Antenna | | |
| Relay Interface | (WR-123, optional). User intend | | Buzzer with two wires | | |
| | to control the electrical appliance, it is | Optional Accessories | | | |
| | not necessary use the wires to connect to the main system if via WR-123. | | | | |
| | | | | | |
| Frequency of | 433.92 MHz. | L | Wireless detect switch, Model: DS-121 | | |
| Wireless | | Other model | 3 band (950/1800/1900 MHz) for | | |
| Detect Switch | | 1 | American marke | | |
| Standard | CE conformity | | Model : GSM-120 | | |

* Appearance and specifications listed in this brochure are subject to change without notice. www.YaLAB.com.tw 02-23890101